



## Printed Circuit Board Solutions

# Quick Turn Availability (QTA) Lead Times

### APCT QTA Production Cycle Times | Times Shown Below Are In Days

Board Description		4L	6L	8L	10L	12L	14L	16L	18L	20L	22L	24L	26L	28L	30L	32L
Conventional Multilayer Build-up	APCT Best	1	1	2	2	2	3	3	3	3	3	4	4	4	4	4
Conventional Multilayer Build-up with Via Fill	APCT Best	3	3	3	3	3	4	4	4	4	4	5	5	5	5	5
Conventional Multilayer Build-up with Blind Via's & Via Fill Laser - CDD - Back Drill	APCT Best	3	3	3	3	3	5	5	5	5	5	5	5	5	5	5
Sequential Build-up N+N (2 subs) (2 x press)	APCT Best	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5
1+N+1 (2 Layer Buried Sub 1x press)	APCT Best	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5
1+N+1 (M/L Buried Sub) (2x press)	APCT Best	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5
2+N+2 (1 Buried Sub) (2x press)	APCT Best	5	5	5	5	5	5	5	5	5	5	5	5	5	5	5
2+N+2 (2 Buried Sub) (3x press)	APCT Best	NA	NA	10	10	10	10	10	10	10	10	10	10	10	10	10
3+N+3 (2 Buried Sub) (3x press)	APCT Best	NA	NA	10	10	10	10	10	10	10	10	10	10	10	10	10
3+N+3 (3 Buried Sub) (3x press)	APCT Best	NA	NA	10	10	10	10	10	10	10	10	10	10	10	10	10
4+N+4 (3 Buried Sub) (4x press)	APCT Best	NA	NA	NA	12	12	12	12	12	12	12	12	12	12	12	12
4+N+4 (4 Buried Sub) (4x press)	APCT Best	NA	NA	NA	12	12	12	12	12	12	12	12	12	12	12	12
Anylayer (Full Stacked Micovia)	APCT Best	5	7	9	12	15	18	20	NA	NA	NA	NA	NA	NA	NA	NA

The information above is offered as a guideline to APCT's Quick Turn Availability Lead Times

10.12.21

**APCT.com**

**APCT Santa Clara HQ**  
 3495 De La Cruz Blvd.  
 Santa Clara, CA 95054  
 Phone: **408.727.6442**

**APCT Anaheim**  
 250 E. Emerson Ave  
 Orange, CA 92865  
 Phone: **714.921.0860**

**APCT Orange County**  
 1900 Petra Lane  
 Placentia, CA 92870  
 Phone: **714.993.0270**

**APCT Wallingford**  
 340 Quinnipiac St. #25  
 Wallingford, CT 06492  
 Phone: **203.269.3311**

**APCT Global**  
 340 Quinnipiac St. #25  
 Wallingford, CT 06492  
 Phone: **203.284.1215**